


ILS or LOC RWY 25
OXNARD (OXR)

MISSED APPROACH: Climb to 520 then climbing left turn to 2000 on CMA VOR/DME R-249 to SQUID INT/14.7 DME and hold.

GND CON
121.9



Knots	60	90	120	150	180
Min:Sec	9:42	6:28	4:51	3:53	3:14